

PRODUCT SPECIFICATION

RUBIX WALL





RUBIX WALL Product Specification



INTRODUCTION

The Rubix Wall compliments our Rubix Recessed and Suspended ranges allowing installations to be completed with aesthetically similar bi-directional wall mounted luminaires. The Rubix wall is ideal for receptions and entrances, corridors, offices and schools or decorative column lighting and provides a 50% up 50% down distribution contributing to light on walls and ceilings to create an attractive lit environment. The diffuse upward optic provides a broad spread of light onto the walls and ceiling whilst the downward optic is glare controlled ensuring compliance to BSEN 12464.

The luminaire housing can be specified in either black or white finishes whilst the downward optic cell surrounds are available in a range of colours including neutral tones such as opal and black through to coloured options ideal for matching corporate themes such as red, orange, green and blue.

From a practical perspective the Rubix wall is available in a range of lumen outputs and all dimming variants. We offer a range of wireless control systems providing localised grouping and control as well as comprehensive wireless solutions allowing both standard and emergency luminaires to be centrally monitored.



RUBIX WALL - APPLICATION

- > Commercial / Offices
- > Corridor
- > Education
- > Healthcare / Social Housing
- > Hotel / Leisure
- > Retail
- > Transport

RUBIX WALL - SPECIFICATION

CONSTRUCTION

- > Housing: 0.7mm CR4 steel
- > Finish: Polyester powder painted BS 00E55 matt white 60% gloss
- > Finish: Polyester powder painted RAL 9006 matt grey
- > Finish: Polyester powder painted RAL 9005 matt black
- Diffuser: Injection moulded high transmission opal polycarbonate cell with miro silver aluminium inserts and injection moulded clip on bezel
- > IP20

PERFORMANCE

- > Part L2 compliant
- > BSEN 12464-1:2011 3000 Candela 65° and UGR 19 compliance
- 3SDCM Three step Macadams ellipse
- > TM21: L90>60K Hours / L80>90K Hours
- > Bi-Directional 50% up 50% down
- > Up to 139 luminaire lumens per circuit Watt.

ENVIRONMENTAL

- > Designed to allow simple replacement of components with commonly available tools in compliance with the Eco Design Directive, please see the installation leaflet for maintenance instructions.
- > Powered by European branded drivers and emergency modules ensuring replacement parts are easily sourced.
- > Every luminaire is labelled with a unique ID number allowing easy identification of spare parts for the lifetime of the product.
- Contains no single use plastics or polystyrene packaging.
- > Supplied in plain card boxes with paper tape ensuring packaging is easily recycled.

- Designed to allow simple disassembly for end of life recycling.
- > UK based manufacturing providing local support throughout the product lifetime and minimising transportation miles.

EMERGENCY

> Not available with emergency

CONTROL

- > Optional compatibility with a range of dimming systems including DALI, DSI and Switch Dimming
- > Optional Integral Reacta-Air wireless presence and daylight regulations sensor
- > Optional integral Reacta-Link for integration with Reacta-Link wireless installations
- > Optional integral Reacta-Control for integration with Reacta-Control wireless installations

INSTALLATION

> Suitable for surface installation

VARIATIONS

- > Available with a wide range of colour temperatures and renderings
- Available in a range of housing sizes and lumen outputs
- > Available in white, black or grey finishes

RUBIX WALL - IMAGES



Rubix Wall White



Rubix Wall Reacta-Air White



Rubix Wall Reacta-Air Black



An office using the Rubix Wall



Costigans-Rhyl Digital Hub using the Rubix Suspended & Rubix Wall



Costigans-Rhyl Digital Hub using the Rubix Suspended & Rubix Wall



Eliot Park using the Rubix Wall




Summit Up using the Rubix Wall





Eliot Park using the Rubix Wall



Eliot Park using the Rubix Wall




Dennistoun Library using the Rubix Wall





DonaldDewar Leisure Centre using the Rubix Wall

RUBIX WALL - TECHNICAL



Rubix Wall

RUBIX WALL - WARRANTY

At Dextra our commitment to service has been at the forefront throughout our history spanning more than forty years in the UK lighting market. Our service ethos extends beyond design and delivery, we believe supporting your installation throughout the warranty period is equally crucial, whilst the strength and longevity of Dextra Group provides peace of mind that our warranty will be supported throughout.

The Dextra range is supplied with a five year warranty commencing from the date of delivery. During the first three years defects will be repaired on site and the warranty will include both parts and labour. For the final two years drivers, emergency modules, wireless modules, sensors and LED circuits will be supplied free of charge to replace defective components, labour and other associated costs are not included.

Certain ranges and components are subject to exemptions:

- Lithium batteries are provided with a five year warranty. During the first three years defects will be repaired on site and the warranty will include both parts and labour. For the final two years replacement batteries will be supplied free of charge to replace defective components. Five year warranty became effective as of 03/02/25, Lithium emergency luminaires supplied prior to this date are supported with a three year on site warranty only. Labour and other associated costs are not included. Nickel Metal Hydride and Nickel Cadmium batteries are provided with a one year warranty for parts and labour.
- Emergency luminaires including AME LED, EXI LED, EXI LED, EXI Track, HBE LED, HBE2 LED, OAT2 LED, OEZ LED and Twinspot are supplied with a one year warranty for parts and labour. Lithium variants suffixed with the 5YR part code, the Autotest emergency with the LA3 part code and wireless variants with LA3RC or LSTR part codes are supplied with a five year warranty. For these extended warranty variants for the first three years defects will be repaired on site and the warranty will include both parts and labour. For the final two years replacement batteries will be supplied free of charge to replace defective components.
- Protec Micro, PTECF7 Fire Rated Downlights, Serenus and the Opus Sconce are provided with a five year replacement luminaire only warranty. Protec FR Fire Rated Downlights are provided with a 2 year replacement luminaire only warranty.
- Controls systems such as standalone sensors, switches, marshalling boxes and cabling are provided with a one year warranty for both parts and labour. DALI control systems are provided with a two year warranty for both parts and labour.
- LEDextra ranges are supplied with a three year parts or replacement luminaire only warranty with the exception of the IMPR RGBW, the Runway RBGW, the MOD RGBW, Tanek RGBW and the DexRing. These five ranges are supplied with our standard five year warranty during which defects within the first three years will be repaired on site and the warranty includes both parts and labour. For the final two years free of charge replacement components only will be supplied to rectify any failures but labour and other associated costs are not included.
- LEDEX ranges are supplied with a three year replacement luminaire only warranty.

• The Decorative Pendant ranges, Bebo, Dene, Nova, Fino and Stix are supplied with a 3 year replacement luminaire only warranty.

All warranties are subject to correct use of the product and will be invalidated by misuse, for example incorrect installation, unsuitable environmental conditions or incorrect maintenance. It is the duty of the customer to ensure that all the fault lies with the luminaire prior to requesting replacement parts or site repairs. In the event that no defect is found with the product our costs for attending site will be recharged to the customer and credit will not be issued against returned products. No consequential losses incurred resulting from any defect with our product will be reimbursed.

Given the nature of LED technology a small percentage of LEDs may fail during the lifetime of a luminaire, this does not cause a reduction in lumen output. As such LED luminaires are only deemed to be faulty for warranty purposes when in excess of ten percent of LEDs have failed in a single luminaire.

On site repair of products under warranty will be undertaken during normal working hours, 9am to 5pm Monday to Friday, and will require unrestricted access to luminaires. Where required Dextra will provide access equipment to carry out repairs at height, should luminaires have been installed in locations where reasonable provision for maintenance access has not been made we reserve the right to supply replacement product only. On site warranty repairs will only be undertaken on the mainland of the UK and Ireland, in all other locations replacement product only will be provided.

If you require any assistance with regards to our products please contact our Customer Services department on 01747 858100.

RUBIX WALL - ORDER CODES

LUMINAIRE CODES

Code	Description	Power	Llm/W
RBXW L30	Rubix Wall, 2,682llm, Opal Cell, Colour 84	19.2W	139
RBXW L45	Rubix Wall, 3,945llm, Opal Cell, Colour 84	29.5W	134

OPTIC

Code	Description	
BLK	Black Cell	
BLE	Blue Cell	
ORA	Orange Cell	
RED	Red Cell	

DIMMING

Code	Description
А	DALI Digital Addressable Lighting Interface
S	Switch Dimming
D	DSI Digital Dimming
Н	HFR Analogue 1-10v
С	Bi-Level Dimming For Standalone Switched Sensor

CONTROL

Code	Description
RAS	Reacta-Air Bluetooth, Wireless, Presence & Daylight, 2.5-3M
RLS	Reacta-Link Wireless, Presence & Daylight, 2.5M-5M

MISCELLANEOUS

Code	Description
C**	Select Colour Temperature and Rendering; C827, C83, C84, C85, C865, C93, C94
BL	Black Finish
GY	Grey Finish
LSF	Low Smoke Zero Halogen

Rubix Wall Installation



220-240V / 50-60Hz IP20

Terminal Labelling:

Power L1 E (

Switched Live Earth Neutral

Emergency L2 DA/AT3 DA/AT3 Dimming -/D1/DA +/D2/DA Neutral
Unswitched Live
DALI Autotest
DALI Autotest

Analogue/DSI/DALI Analogue/DSI/DALI Switch Dim / Corridor Function









WARNING: Luminaire must be earthed. Risk of electric shock from LED boards if operated with cover removed. Installation / operation outside of luminaires intended scope invalidates warranty. Suitable only for domestic / light industrial / industrial applications within the scope of EN55015. Tested to compliance with BSEN 60598: specification for general requirements and tests. Must be installed by a suitably qualified person in accordance with all relevant legislation. Ambient operating temperature of 0°C to 25°C. If maximum operating temperature is exceeded luminaire will automatically dim / switch off. Terminal blocks are rated to 16A unless stated otherwise. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person. LUMINAIRES WITH EMERGENCY PACK: When supply is isolated battery output terminals may be live if battery is connected. Isolate mains and battery before servicing. Emergency luminaires require unswitched live connection taken from same phase as switched supply. When unswitched supply is connected status indicator illuminates green, when unswitched supply is disconnected indicator extinguishes and luminaire operates in emergency mode. 24 hour charge period required before undertaking full discharge test. Emergency test sheets provided should be used to record all emergency tests. Batteries should be replaced when 3 hour duration is not met. Excessive switching of permanent live may result in premature battery failure. Battery electrolyte can be harmful to eyes / open wounds, do not puncture. If electrolyte touches skin / eyes flush with water. Do not incinerate batteries.

1. Fitting will be supplied complete. You will need to remove the wall mount bracket from the back of fitting in order to mount




2. Firstly unscrew the 3 screws along the back edge of the fitting. This will release the wall mount bracket.




3.

Slide wall mount bracket out from the back of the fitting.




4.

Screw the wall mount bracket to the wall using the two fixing points.




Then feed cable though the central hole and make the electrical connection to the terminal block.

5.




Offer the fitting back up to the wall mount bracket.

Connect the wall mount bracket to the fitting with the 2 pin plug and the earth cable to the brass tag.



6.

Once connections have been made, slide the fitting onto the arms of the wall mount bracket.



Rubix Wall Installation



7. 8. Ensure fitting is pushed flush to the wall Installation is now complete. before the 3 screws are tightened. Maintenance LED 1) Disconnect luminaire before Driver Circuit undertaking any maintenance or cleaning. 2 Cleaning should be undertaken on external parts of the luminaire only using a slightly damp lint free cloth. 3 To access housing use a pan pozi screwdriver to remove cover. (4) Use a pan pozi screwdriver (5) Please contact Dextra for assistance to remove components. with spare component supply.